Tenter Weg 2-8 ● 42897 Remscheid ● Germany Fon +49-2191-9672-0 ● Fax -40 www.ghm-messtechnik.de ● info@honsberg.com

#### **Product Information**

# **GHM-HONSBERG**

#### LABO-RRI-I / U / F / C

# Flow Transmitter LABO-RRI-I / U / F / C



- Uncomplicated measurement of flow rates
- No magnets; uses inductive sensor
- Long working life thanks to high quality ceramic axis and special plastic bearing
- Run-in and run-out sections are not necessary.
- Modular construction with various connection systems
- Plug-in and rotatable connections
- 0..10 V, 4..20 mA, frequency/pulse output, completely configurable
- Optionally, non-return valve, filter, constant flow rate device in the connections

#### Characteristics

The flow meter consists of a spinner which is rotated by the flowing medium. The rotor's rotational speed is proportional to the flow volume per unit time. The rotor is fitted with stainless steel clamps (optionally titanium or Hastelloy®). An inductive proximity switch records the rotational speed, which is proportional to the flow rate.

The LABO-RRI electronics make various output signals available:

- Analog signal 0/4..20 mA (LABO-RRI-I)
- Analog signal 0/2..10 V (LABO-RRI-U)
- Frequency signal (LABO-RRI-F) or
- Value signal Pulse / x Litres (LABO-RRI-C)

A model with switching output is also available.

If desired, the range end value can be set to the currently existing flow using "teaching".

#### **Technical data**

Sensor	inductive						
Nominal width	DN 10 (FLEX-RRI-010)						
	DN 25 (FLEX-RF						
Mechanical	female thread G	³/ <sub>8</sub> , G 1					
Connection	male thread G 3/s						
	hose nozzle Ø11						
		crimped, and plug-in nections with constant flow					
		niters available on request)					
Metering ranges	0.1100 l/min						
3 3	for details, see to	able "Ranges"					
Measurement accuracy	±3 % of the mea	sured value					
Repeatability	±1 % of full scale	e value					
Pressure loss	max. 0.5 bar						
Pressure	PN 16 bar						
resistance	0.00.00						
Medium temperature	060 °C						
Storage temperature	-20+80 °C						
Materials	Housing	PPS					
medium-contact	Datas	(Fortron 1140L4)					
	Rotor	PVDF					
	Clamps	1.4310 optionally:					
		titanium or Hastelloy®					
	Bearing	Iglidur X					
	Axis	Ceramic Zr0 <sub>2</sub> -TZP					
	Seal	FKM					
Materials, non-	Clamps	1.4301					
medium-contact	Electronic	CW614N nickelled					
Description of the control of the co	housing	Name of the second					
Supply voltage	1030 V DC at v 1530 V DC	oltage output 10 V:					
Power	< 1 W (for no-loa	d outputs)					
consumption		state to star A or software or here					
Output data:	all outputs are re reversal polarity	sistant to short circuits and protected					
Current output:		nA available on request)					
Voltage		available on request)					
output:	Output current m						
Frequency	transistor output "push-pull"						
output:	l <sub>out</sub> = 100 mA ma						
	output frequency	standard 500 lmn/l					
	metering range, standard 500 Imp/l (corresponds to 666.7 Hz at 80 l/min)						
		values: 5000 Imp/l					
	(corresponds to 500 Hz at 6 l/min) (other frequencies available on request)						
Duleo output	The state of the s						
Pulse output:	transistor output I <sub>out</sub> = 100 mA ma						
	pulse width 50 m						
30050	pulse per volume						
Display	yellow LCD shows operating voltage (LABO-RRI-I / U) or output status						
		) or output status C) (rapid flashing =					
	Programming)	/ (lapid lidoliling -					
Electrical connection		onnector M12x1, 4-pole					
Ingress protection	IP 67						
Weight	LABO-RRI-010	approx. 0.2 kg					
•	LABO-RRI-025	approx. 0.5 kg					
Conformity	CE	1.12					
	L						

... professional Instruments "MADE IN GERMANY"



Tenter Weg 2-8 ● 42897 Remscheid ● Germany Fon +49-2191-9672-0 ● Fax -40 www.ghm-messtechnik.de ● info@honsberg.com


### www.ghm-messtechnik.de • info@honsberg.com Product Information LAB


### Signal output curves

Value x = Begin of the specified range = not specified range


Current output

Voltage output





Frequency output




 $f_{\text{max}}$  selectable in the range of up to 2000 Hz

Other characters on request.

#### Ranges

Metering range I/min (H <sub>2</sub> O)	Types	Q <sub>max</sub> I/min (H <sub>2</sub> O)
0.1 1.5	LABO-RRI-010020	1.8
0.2 10.0	LABO-RRI-010050	12.0
0.4 12.0	LABO-RRI-010070	14.4
2.0 30.0	LABO-RRI-025080	36.0
3.0 60.0	LABO-RRI-025120	72.0
4.0100.0	LABO-RRI-025160	120.0

#### Wiring



Connection example: PNP NPN




Before the electrical installation, it must be ensured that the supply voltage corresponds to the data sheet.

### CHM-HONSBERG LABO-RRI-I/U/F/C

It is recommended to use shielded wiring.

The push-pull output) of the frequency output version can as desired be switched as a PNP or an NPN output.

#### **Dimensions**



#### Threaded connection

G	DN	Types	H/L	L1	В	С	E	F	X	SW
G 3/8	10	RRI-010G	50	84	29	12.5	16.5	56	12	22
G 3/8 A		RRI-010A							14	
G 1	25	RRI-025G	70	110	53	23.0	27.5	51	18	38
G1A		RRI-025A		122						

#### Hose nozzle connection

D	DN	Types	H/L	L1	В	С	E	F	X
Ø11	10	RRI-010T	50	96	29	12.5	16.5	56	21
Ø30	25	RRI-025T	70	176	53	23.0	27.5	51	45

#### Handling and operation

#### Installation

The Rototron device is installed in the pipework with the aid of the rotatable adapter pieces. If necessary, the adapters can be removed from the body of the housing after the stainless steel clips have been removed from the housing. Before reinstalling, it should be ensured that both the adapter with the O-ring and the sealing surface in the body are clean and undamaged. The adapters should be fitted carefully in the housing (it is best to turn them), so that the O-ring is not damaged.

With this flow sensor, there is no need for run-in and run-out sections. However, it should be ensured that the flow sensor is at all times filled with medium. Any preferred installation position is possible, but the best possible venting position should be chosen (rotor axis horizontal, flow horizontal or from bottom to top).

Air bubbles affect the measurement results. For filling processes, the valve should be installed behind the sensor. A running up time of approx. 0.5 seconds and a running down time of approx. 3 seconds should be noted.

Tenter Weg 2-8 ◆ 42897 Remscheid ◆ Germany Fon +49-2191-9672-0 ◆ Fax -40

www.ghm-messtechnik.de • info@honsberg.com



#### LABO-RRI-I / U / F / C

### **Product Information**

#### Note

The metering range end value can be programmed by the user via "teaching". Requirement for programmability must be stated when ordering, otherwise the device cannot be programmed. The ECI-1 device configurator with associated software is available as a convenient option for programming all parameters by PC, and for adjustment.

The teaching option is not available for the pulse output version.

#### **Operation and programming**

The teaching process can be carried out by the user as follows:

- The flow rate to be set is applied to the device.
- Apply an impulse of at least 0.5 seconds and max. 2 seconds duration to pin 2 (e.g. via a bridge to the supply voltage or a pulse from the PLC), in order to accept the measured value.
- When the teaching is complete, pin 2 should be connected to 0 V, so as to prevent unintended programming.

The devices have a yellow LED which flashes during the programming pulse. During operation, the LED serves as an indicator of operating voltage (for analog output) or of switching status (for frequency or pulse output).

In order to avoid the need to transit to an undesired operating status during the teach-in, the device can be provided ex-works with a teach-offset. The teach-offset point is added to the currently measured value before saving. The offset point can be positive or negative.

Example: The end of the metering range should be set to 80 %. However, only 60 % can be achieved without problem. In this case, the device would be ordered with a "teach-offset" of +20°%.. At a flow rate of 60 % in the process, teaching would then store a value of 80 %.

If necessary, a far greater number of parameters can also be programmed using the ECI-1 device configurator.

#### Ordering code

The basic device is ordered e.g. RRI-010xxx with electronics e.g. LABO-RRI-010xxx

_	1.	2.	3.	4.	5.	6.	7.	8.	9.
RRI-									E
		eto:		198001					
		10	11	12.					
LABO-R	RI-								

O=Option

1.	Nomi	nal	width					
	010		DN 10					
	025		DN 25		]			
2.	Mechanical connection							
	G		female thread					
	Α		male thread		l			
	Т		hose nozzle		l			
3.	Conn	ecti	on material		l			
	V		PVDF		l			
	M		CW614N nickelled		l			
	K		1.4305		l			
4.	Hous	ing	material		l			
	Q		PPS		l			
	V		PVDF		l			
	Α		PPS with transparent cover PSU		l			
5.		ds f	low drilling		ļ			
	020		Ø 2.0		ļ			
	050		Ø 5.0		ļ			
	070		Ø 7.0		ļ			
	080		Ø 8.0	•	ļ			
	120		Ø12.0	•	ļ			
830	160		Ø16.0	•				
6.	Seal r	mate	24 Start grad 40 Start 20 Star					
	V		FKM					
	E	_	EPDM					
22	N		NBR					
7.	Rotor				_			
	10	_	with 10 clamps		_			
	02	_	with 2 clamps		_			
	05		with 5 clamps		_			
8.		ial f	or clamps					
	K		1.4310		_			
	T		titanium					
0	Н		Hastelloy®		_			
9.	0.00	ecti	on for electronics					
	E		electionics					
10.	Signa	l ou						
	ļ		current output 420 mA					
	U		voltage output 010 V					
	F		frequency output (see "Ordering information")					
	С		pulse output (see "Ordering information")					
	Progr	amı			_			
11.	I A I		cannot be programmed (no teaching)					
11.	N				_			
11.	Р	0	programmable (teaching possible)					

Tenter Weg 2-8 • 42897 Remscheid • Germany Fon +49-2191-9672-0 • Fax -40

www.ghm-messtechnik.de • info@honsberg.com

## (GHM)-HONSBERG

#### LABO-RRI-I / U / F / C

l/min

l/min

#### **Product Information**

#### Required ordering information **Options for LABO** For LABO-RRI-F: Special range for analog output: Output frequency at full scale <= metering range (standard=metering Maximum value: 2.000 Hz Special range for frequency output: For LABO-RRI-C: <= metering range (standard=metering For the pulse output version, the volume (with numerical value and unit) which will correspond to one pulse must be stated. Power-On delay period (0..99 s) (time after applying power during which the Volume per pulse (numerical value) outputs are not activated or set to defined values) Volume per pulse (unit) Further options available on request. **Options** Rotor with titanium clamps

Accessories

- Cable/round plug connector (KB...) see additional information "Accessories"
- Evaluation electronics OMNI-TA
- Device configurator ECI-1